


# SX300 SERIES MICROPROCESSOR BASED COUNTER





The SX300 counter is a microprocessor based, 6 digit counter housed in a standard DIN style case (68mm square cutout). The small case and front bezel require minimal panel space, yet provides large, easy to use programming keys and an easy to read .36 inch high LED display.

The SX300 counter is designed for a single direction count input from a solid state sensor or switch. The DC input versions will count up to 2500 counts per second. The AC input version will count up to 2500 counts per minute. Two individually programmable relays provide a wide variety of output combinations to suit most any application.

The SX300 counter provides a number of features normally found on larger and more expensive counters. These features are programmed using rocker switches on the back of the unit for simplicity and security.

Among the features of the SX300 counter are:

- NEMA 4 Hosedown Test rated.
- Two 5 Amp SPDT relay outputs.
- Eight output operating modes programmable for one or both outputs.
- Early Trip prewarn operation programmable for one output.
- Count input scaling using either a .0001 to 99.9999 multiplier or a 1 to 999999 divider.
- Programmable display decimal point position.
- Setpoint to zero or zero to setpoint cycle progress indication.
- LED indicators for output status.
- Program and setpoint changes may be made while the unit is operating.
- Front panel reset key and remote reset input.
- Keypad lock function.
- Non-volatile memory (NOVRAM) for program and data retention.
- · Removable terminal blocks for wiring connections.
- +12 VDC sensor power supply.

## **SPECIFICATIONS**

### **Operating Voltage and Frequency**

 Symbol
 Voltage & Frequency

 A6
 120 VAC
 50/60 Hz

 B6
 240 VAC
 50/60 Hz

#### Count Input Voltage and Frequency

 Symbol
 Voltage & Frequency

 SX311
 10.5-28 VDC

 SX312
 120 or 240 VAC 50/60 Hz

(Depending on unit operating voltage)

SX313 2.4-5 VDC

#### Count Speed

 $\begin{array}{l} {\rm SX311/313-2500\; counts\; per\; second\; (DC)} \\ {\rm SX312-2500\; counts\; per\; minute\; (AC)} \end{array}$ 

 SX311/313
 SX312

 Minimum ON time
 200 μSec
 12 mSec

 Minimum OFF time
 200 μSec
 12 mSec

#### **Sensor Power Supply**

+12 VDC, 100 milliamps maximum

#### **Power Requirement**

8 VA operating12 VA with both relays energized

#### **Setting Accuracy**

Count - 100%

Pulse Output Time — .05% of setting or 50 milliseconds whichever is larger

#### Repeat Accuracy

Count — 100%

Pulse Output Time — .001% of setting or 35 milliseconds whichever is larger

#### Power On Response Time

200 milliseconds

#### **Reset Time**

15 milliseconds

#### **Operating Temperature Range**

+32º to 122ºF (0-50ºC)

#### **Output Rating**

Relay - 5 amp, 10-240 VAC

#### Vibration

Unit function is unaffected by 2.5s sinusoidal vibration magnitude in both directions of the perpendicular mounting axes imposed from 20 to 100 Hz.

#### Static Discharge

Unit function is unaffected by a constant 3600 volt peak, 60 Hz discharge applied to the front plate at a relative humidity of less than 25%.

#### **Transient Protection**

Immune to 2500 volts peak transients up to 50 microseconds in duration.

## **Eagle Signal Controls**

A Division of Mark IV Industries, Inc. 8004 Cameron Road, Austin, Texas 78753 U.S.A.





#### **CONTROL INPUT FEATURES**

The SX300 counter uses all line voltage control inputs for high noise immunity.

The start input is used to enable the counter to register counts and to energize the outputs. This allows the count operation to be started independently of when power is applied to the unit. This input can be programmed to respond to sustained or momentary inputs.

A line voltage remote reset input is also provided which resets the counter and deenergizes the outputs when power is applied to this terminal.

#### **COUNT INPUT FEATURES**

Three models of the SX300 counter series are available for different count sensor applications:


SX311 10.5-28 VDC input

SX312 120 or 240 VAC line input

SX313 2.4-5 VDC input

All versions of the SX300 series have optically isolated inputs. The DC count version can be used with either NPN sinking or PNP sourcing switch inputs without special user configuration.

A 12 VDC 100 milliamp power supply output is standard on all models to provide count sensor power.



#### **OUTPUT FEATURES**

There are two 5 amp SPDT relay outputs on the SX300 counter. LED indicators in the display show when these outputs are energized.


### **Output 1 Operating Modes**

Output 1 is programmable for eight operating modes.


1. ON Delay — Output 1 is energized at the end of the counting cycle.



2. Interval — Output 1 is energized during the counting cycle.



- **3 & 4.** The ON Delay and Interval modes are also available with count totalization. In these modes the display will continue to indicate counts registered after the count cycle is complete.
- **5. Timed Pulse Output** Output 1 is energized for a programmable pulse time up to 99.99 seconds at the end of the count cycle.





**6. Timed Pulse and Repeat** — Output 1 is energized for a programmable pulse time up to 99.99 seconds at the end of the count cycle, with the count cycle automatically repeating.




7 & 8. Repeat Cycle, ON or OFF Count Cycle First — Output 1 is energized and deenergized in repeating operation with either the ON or OFF count period first. The count periods are equal length, but unequal length count intervals can be obtained using the Early Trip prewarn output.



OFF Count Period First Shown

### **Output 2 Operating Modes**

The second output on the SX300 counter can be programmed to operate either in parallel to Output 1, providing DPDT relay operation from the two SPDT relays, or it can be programmed as an Early Trip prewarn output that will be energized a number of counts before the end of the cycle. An example of Early Trip prewarn operation with the ON Delay mode for Output 1 is shown here for reference.



#### **RESET OPERATION**

The SX300 counter is programmable to either reset on power interruption and start over when power is reapplied or to retain its actual cycle progress value and continue with the cycle when power is reapplied.

#### COUNT INPUT SCALING

The SX300 counter can be programmed to scale count inputs in order to provide settings and cycle progress display in engineering units relevant to the process being measured. The SX300 counter offers two programmable modes of count input scaling. A .0001 to 99.9999 multiplier scale factor is available for cut-to-length and unit conversion applications. A 1 to 999999 divider scale factor is also available for direct count-to-unit applications such as flow control.

## **DISPLAY DECIMAL POINT POSITION**

0.0.0.0.0


The SX300 display has a programmable decimal point that can be positioned between any of the 6 digits to show correct units of measure.

## CYCLE PROGRESS INDICATION

The SX300 count progress display can be programmed either to cycle DOWN from the setpoint to zero or to cycle UP from zero to the setpoint.

#### FRONT PANEL PROGRAMMING

The SX300 counter uses a sealed front panel keypad for entry of variable data such as setpoints.



Pressing the SET key calls the setpoint to the display. The setpoint will be displayed with the least significant digit flashing. The position of the flashing digit is controlled using the  $\blacktriangleleft$  key. The  $\blacktriangle$  and  $\blacktriangledown$  keys increment and decrement the value of the flashing digit. The ENT key enters any setpoint changes into memory.

In addition to changes to the main setpoint, the front keypad is also used to change the scale factor, the Early Trip setpoint for Output 2, the timed pulse output length, and the display decimal point position. This programming is done with a prompted set-up routine. The SET key is used to scroll through the prompts and variables. To enter the prompted set-up routine it is necessary to press and hold the SET key for at least 5 seconds, This prevents inadvertant entry into the set-up routine.

The RST key on the front panel is a manual reset. Pressing the RST key resets the counter and holds the outputs in their normal, deenergized states until the key is released.

A keypad lock function is provided for security. Pressing and holding the ENT key for about five seconds will alternately lock and unlock the front keypad. When locked, the SET key will call all variables, but the ◀, ▲, and ▼ keys will be inoperative so that changes cannot be made. The RST key is also inoperative when the keypad is locked.



#### SWITCH PROGRAMMING


The SX300 counter uses eight switches on the back of the unit for programming the operating modes as follows:

X = Switch ON O = Switch OFF Blank = Does Not Apply

SYM.	OPERATING MODE	SWITCH NUMBER								
		1	2	3	4	5	6	7	8	
OUTPUT 1 OPERATION										
1	ON Delay	0	0	0						
2	ON Delay & Totalize	0	0	Х						
3	Interval	Х	0	0						
4	Interval & Totalize	Х	0	Х						
5	Timed Pulse	0	Х	0						
6	Timed Pulse & Repeat	Х	Х	0						
7	Repeat - OFF First	0	Х	Х		<u> </u>				
8	Repeat - ON First	Х	Х	Х					<u> </u>	
OUTPUT 2 OPERATION										
1	Same as Output 1				0				<u> </u>	
2	Early Trip Prewarn	<u> </u>		<u> </u>	X	L	<u>L</u> .	<u> </u>	<u>L</u>	
CYCLE PROGRESS										
1	Down - From setpoint				ļ		1		1	
	down to zero	<u> </u>	ـ	<u> </u>	├-	0	<u> </u>	<u> </u>	ļ	
2	Up - From zero up to setpoint	L	<u></u>	L	L	X	<u></u>	L	<u> </u>	
SCALE FACTOR										
1	Divider - 1 to 999999	<u> </u>	<u> </u>	Ļ_	<u> </u>	ļ_	0	ļ	<u> </u>	
2	Multiplier0001 to 99.9999	<u>L</u>		<u>L_</u>	L	<u></u>	X	<u></u>	<u></u>	
RESET MODE										
1	Reset on Power Interruption	_	1	L	1	1_	ļ	0	┖	
2	Non-Reset on Power Interruption		<u>_</u>	<u></u>	丄	<u></u>	<u></u>	<u>X</u>	<u></u>	
START MODE										
1	Sustained Start Input	1	1	1_	1	1_	1_	<u> </u>	0	
2	Momentary Start Input		丄	丄	<u>L</u>	1	<u></u>	<u>L</u>	X	

#### TERMINAL ASSIGNMENTS

The SX300 counter series uses two removable terminal blocks to provide wiring connections, with the following terminal assignments.




#### MOUNTING

12

13

The SX300 counter uses two removable mounting clips with adjustable screws to mount the enclosure in a panel as shown below.



#### 

## **OPERATING VOLTAGE & FREQUENCY**

-	SYMBOL	DESCRIPTION
	A6	120 VAC 50/60 Hz
	B6	240 VAC 50/60 Hz

2.4-5 VDC

120 or 240 VAC\*

<sup>\* 120</sup> VAC if A6 Operating Voltage is Selected 240 VAC if B6 Operating Voltage is Selected